

ESCREO



INITIAL PREPARATIONS

1. Each box includes: installation instructions, whiteboard paint, paint hardener, can opener and stirrer.
2. You will also need: paint roller, tape, protective cover, sanding block, gloves and tape (optional).
3. Use tape to frame your ESCREO area (optional).
4. Smooth the surface with the sanding block.
5. Use the gloves and, if possible, eye protection.

Watch our video tutorials in ESCREO YouTube Channel.



FIND THE SECTION THAT APPLIES TO YOU

WHITEBOARD PAINT or HOME WORKS

/Apply the paint no later than 2 hours after mixing the 2 components/

1. Open the tins with the tin opener carefully.
2. Mix the 2 components with the stirrer for 5 mins.
3. **ONLY** if the sticker on the top of the tin contains **E1**: add 50 grams of water per 1m².
4. Pour half of the mixture into a tray.
5. Close the rest of the paint in the tin.
6. Apply the 1st layer evenly with a paint roller/brush.
7. Wait between 30 mins and 45 mins.
8. Apply the 2nd layer and proceed to "Wrap-up!" section.
9. After mixing the two components **DO NOT** leave the mixture with a closed lid for more than 2 HOURS. If not applied up to 2 hours and let closed, it might pop up.

PRIMER

/To change the colour of the surface or after applying the magnetic paint base/

1. Use an extra tray and a paint roller sleeve to apply the 1st layer.
2. Wait between 30 and 60 mins.
3. Apply the 2nd layer.
4. Wait between 30 and 60 mins.
5. Proceed to "Whiteboard paint or Home Works" section if it is to be applied on top.

MAGNETIC WHITEBOARD PAINT - BASE

/1 extra day for the application process/

1. Stir well the magnetic paint.
2. Use an extra paint tray & roller to apply the 1st layer.
3. Wait 30 mins.
4. Apply the 2nd layer.
5. Wait 45 mins.
6. Apply the 3rd layer.
7. Wait 60 mins.
8. Apply the 4th layer.
9. Remove the tape.
10. Wait for 12 hours.
11. Smooth the surface with the sanding block in straight motions.
12. Proceed to "Primer" section.

WRAP UP!

/NB! Only start writing 3 days after the paint has dried/

1. Make sure the paint is distributed evenly.
2. Remove the painting tape.
3. Place the "Wet Paint" sign.
4. Let it dry for 3 days before using the wall.
5. Check our website for maintenance guidelines.