

Maintenance Guidelines

ESCREO

✔ You should:

- Use the **ESCREO accessories** or other high quality whiteboard materials for writing and erasing.
- Erase with a **soft foam sponge** or a microfiber cloth. You can also use water with the microfiber cloth.
- Use the **ESCREO spray** with the microfiber cloth from your accessories set for deeper cleaning when needed. If needed, you can repeat until your surfaces shine like new.
(ESCREO spray use - no more than twice per month)

✘ You shouldn't:

- Use the deep cleaning spray for the **first 1 month** after painting your surfaces.
- Write with the whiteboard markers immediately after the use of ESCREO spray, wait instead for at least **1 hour**.
- Use **permanent and flip chart markers**. If you do - immediately go over the spot with a whiteboard marker and erase. You can also try with ESCREO spray.
- Erase with **hard or abrasive materials** and clean the markers shadows with degreasers, nail polishers, diluents or other aggressive cleaning chemicals.

We are here to help: hello@escreo.com